

Abandon Ship Life Preserver Tip 006
Manual Inflator

1. Manual Inflator (NSN 4220-01-493-5995) – This manual inflator is to be used with the Abandon Ship Life Preserver . This inflator is activated by pulling on a lanyard on the manual inflator. The manual inflator is mounted on the brass manifold on the buoyancy chamber. A breakaway clip can be used instead of shearwire to keep the inflator from being inadvertently actuated.



Breakaway clip, NSN 4220-01-515-6476)

Manual Inflator